

PRODUCT INFORMATION

LUMINA

 10 - 100 kg

 39 - 90 mm

 35 - 75 mm



TENTE

BETTER MOBILITY. BETTER LIFE.

HOUSINGS

PAGES: 4-9

WHEELS

PAGES: 10-15

FITTINGS

PAGES: 16-23



BETTER MOBILITY IN PREMIUM QUALITY

TENTE believes in smart mobility solutions which noticeably improve people's lives and their work environment. TENTE solutions increase productivity, ensure safety and open up new horizons in matters of design and durability as well as environmental friendliness. Leading manufacturers and companies of different industries rely on these competencies as well as our high production quality.

On the following pages you will find technical information about our Lumina product family. We will also demonstrate the added value this mobility solution offers to your organisation. Features include:

Colour matching

The colour of solid material can be adapted to the product design.

Visual integration

Different dome diameters and designs for a perfect transition from the castor to the application.


Variable fitting options

Wide range of fittings in various sizes.

HOUSINGS



FEATURES




Visual integration

Different dome diameters and designs for a perfect transition from the castor to the application.



Compliant version

Used for furniture (EN12528) and office chairs (EN12529 and BIFMA).



Optimised manoeuvrability

Twin wheel castor with high manoeuvrability due to differential effect.



Painted surface

Gold, chrome, aluminium or glossy colours.



Ergonomic foot pedal

Easily accessible pedal for manual wheel lock.



Reduced risk of accidents

Automatic load-dependent wheel brake to prevent accidents with office chairs.



Prevents unintended movement

Wheel lock with pedal for manual operation.



Colour matching

The colour of solid material can be adapted to the product design. Please contact us for your desired colour.



Robust housing

Twin wheel castor for high stability and low height.

HOUSINGS

The Lumina range offers five types of housings to match the needs of your application. The housings are made of premium quality virgin polypropylene or polyamide. The materials are tested in our own laboratory for compliance with European standards. Non hazardous materials are used in order to comply with the RoHS directive and REACH regulation of the European Union. All product versions can be customised with colours and a large range of fittings.

Chair and furniture castors with wheel diameter 50 mm



Description	 Housing type	Swivel castor	Swivel castor with intermittent brake	Swivel castor with wheel brake	Swivel castor	Swivel castor with wheel brake
	Article description	AA20	AA23	AA25	A520	A525
	Material	Polypropylene	Polypropylene	Polypropylene	Polypropylene	Polypropylene
	Swivel bearing	Plain bearing	Plain bearing	Plain bearing	Plain bearing	Plain bearing
	Castor height without fitting	54,5 mm	54,5 mm	54,5 mm	57 mm	57 mm
	Blind hole Ø	8 mm 10 mm	8 mm 10 mm	8 mm 10 mm	8 mm	8 mm
	Castor width	55 mm	55 mm	55 mm	54 mm	54 mm
 Swivel interference	Wheel Ø 50 mm	104 mm	104 mm	120 mm	104 mm	120 mm



Swivel castor

Wheel and housing are free to move for an easy manoeuvrability.



Wheel brake


Wheel brake with pedal for manual operation that prevents unintended movement.



Intermittent brake

Reduced risk with automatic load-dependent wheel brake to prevent accidents. These products match the requirements of EN 12529 for swivel chairs.

Swivel bearing



Plain bearing for plug-in fittings.



Swivel castor	Swivel castor with intermittent brake	Swivel castor	Swivel castor with intermittent brake
6A20	6A23	A520	A523
Polypropylene with zinc die cast cover	Polypropylene with zinc die cast cover	Polypropylene	Polypropylene
Plain bearing	Plain bearing	Plain bearing	Plain bearing
55,5 mm	55,5 mm	57,5 mm	57,5 mm
8 mm 10 mm	8 mm 10 mm	10 mm	10 mm
55 mm	55 mm	55 mm	55 mm
108 mm	108 mm	102 mm	102 mm



Different wheel treads

Noise-reducing soft wheel version is made of thermoplastic rubber. Hard wheel version, with a polyamide tread, also available.



Big colour range

Castors with chrome or gold finish are available as well.



Different domes

Different diameters allow the castor to be integrated into your product design.



Robust cover

Cover made of solid zinc die cast or synthetic materials.



Classic reliable design

These classically designed castors offers a big colour range. Customised colours also possible.

Small furniture castors with wheel diameter 35-42 mm



Description	 Housing type	Swivel castor	Swivel castor with wheel brake
	Article description	5520	A525
	Material	Polyamide	Polypropylene
	Swivel bearing	Plain bearing	Plain bearing
	Castor height without fitting / wheel diameter in mm	39 mm / \varnothing 35 44,5 mm / \varnothing 40 48,5 mm / \varnothing 42	44,5 mm / \varnothing 40
	Blind hole \varnothing	8 mm	8 mm
	Castor width / wheel diameter in mm	38 mm / \varnothing 35 38 mm / \varnothing 40 37 mm / \varnothing 42	- 38 mm / \varnothing 40 -
Swivel interference 	Wheel \varnothing 35 mm	71,5 mm	-
	Wheel \varnothing 40 mm	72 mm	102 mm
	Wheel \varnothing 42 mm	85 mm	-

Items with this sign "-" are not available in our standard range. Please contact us.



Different wheel treads

Noise-reducing soft wheel version is made of thermoplastic rubber. Hard wheel version, with a polyamide tread, also available.



Aluminium painted version

Castors with silver finish are also available.



User friendly brake pedal

Wheel brake with pedal for manual operation that prevents unintended movement.

Furniture castors with wheel diameter 75 mm



Description	 Housing type	Swivel castor	Swivel castor with wheel brake
	Article description	5520	5525
	Material	Polyamide	Polyamide
	Swivel bearing	Plain bearing	Plain bearing
	Castor height without fitting	90 mm	90 mm
	Blind hole \varnothing	11 mm	11 mm
	Castor width	65 mm	65 mm
Swivel interference 	Wheel \varnothing 75 mm	149 mm	210 mm

WHEELS



FEATURES



Quiet rolling

Soft wheel versions for a quiet working environment.




Colour matching

Colours can be adapted to match the product design. Please contact us for your desired colour.



Reduced cleaning

Due to its mainly smooth surfaces, the castors are quick and easy to clean.




Non-staining operation

Non-staining on contact with floors during long standing periods. Can also be used for floors made of untreated wood and natural stone.



Chemical-resistant components

Insensitive to many cleaning agents and chemical substances.



Non-marking movement

Wheels with reduced abrasion and little cleaning requirement.



Non-hazardous materials

Complies with the RoHS directive and REACH regulation of the European Union. Does not contain polycyclic aromatic hydrocarbons or chromium (VI).

WHEELS

The characteristics of the wheel depend on the material. These wheels have minimal cleaning requirements and benefit from non-marking movement and non-staining contact with floors during long standing periods. They can be use for all kind of floors, from untreated wood to natural stone or soft carpet.



• **Basetech**

Hard-wearing lightweight polypropylene wheels.



• **Basetech conductive**

Electrical conductive version of our Basetech wheel.



Supratech

Smooth running all-rounder with thermoplastic rubber tread.



Supratech conductive

Electrical conductive version of our Supratech wheel.



Duratech

Stable and indestructible, made of polyamide and thermosetting plastic.



Maxtech

Perfect for functional design, injection-moulded polyurethane.

Technical data and availability



		Basetech	Basetech conductive	Supratech	Supratech conductive
Description	Product name	Basetech	Basetech conductive	Supratech	Supratech conductive
	Article description	POI	YOI	PJI	YGI
	Tread material	Polypropylene	Polypropylene	Thermoplastic rubber	Thermoplastic rubber
	Tread hardness	Shore D 65	Shore D 65	Shore A 87	Shore A 87
	Wheel body material	Polypropylene	Polypropylene	Polypropylene	Polypropylene
	Temperature range	-10 °C / +40 °C	-10 °C / +40 °C	-10 °C / +40 °C	-10 °C / +40 °C
	Electric conductive (10 ⁴ OHM)	-	●	-	●
Bearing type	Plain bearing	●	●	●	●
	Wheel Ø 35 mm	-	-	-	-
Load capacity	Wheel Ø 40 mm	10 kg	-	-	-
	Wheel Ø 42 mm	30 kg	-	-	-
	Wheel Ø 50 mm	40 kg	40 kg	40 kg	40 kg
	Wheel Ø 75 mm	-	-	-	-

Items with this sign "●" are available. Items with this sign "-" are not available in our standard range. Please contact us. The mentioned load capacity is only valid for the Lumina product family.

Bearing types



Plain bearing for short distances.



Duratech	Maxtech
UOI	UAI
Polyamide	Polyurethane
Shore D 75	Shore A 92
Polypropylene	Polyamide
-10 °C / +40 °C	-10 °C / +40 °C
-	-
●	●
20 kg	-
-	-
-	-
-	-
100 kg	100 kg



Load capacity

The load capacity depends on the housing and wheel. It has been tested and fulfills the requirements of EN 12528. Castors with intermittent brake fulfills the requirements of EN 12529. When using four castors, you can calculate the necessary load capacity as follows: The sum of the weight of your application plus the additional load divided by three castors.

$$\frac{\text{Weight of application} + \text{load}}{3} = \text{Load capacity of one castor}$$

FITTINGS




FEATURES




Fast assembly

Faster assembly thanks to easy plug-in fittings.



Variable fitting options

Wide range of fittings in various sizes.



Quiet rolling

Noise-reduced fittings for a quiet working environment.



Tested quality

Tested in our own test laboratory for compliance with European standards.

PLUG-IN PLATE FITTINGS

For castors with a blind hole, different plug-in plate fittings are available.



Technical data and availability



Description	Fitting type	Stem with U-shaped plate	Stem with L-shaped plate	Stem with plate	Stem with plate	Stem with plate	Stem with plate
	Article description	P10-40	P11-40	P41	P41	P41	P40
	Size of plate	40 x 15 mm 40 x 16 mm 40 x 17 mm 40 x 18 mm 40 x 19 mm 40 x 20 mm 40 x 21 mm 40 x 22 mm 40 x 25 mm	40 x 16 mm 40 x 17 mm 40 x 19 mm 40 x 22 mm 40 x 25 mm	30 x 30 mm	38 x 38 mm	42 x 42 mm	60 x 60 mm
	Plate hole centres	32 mm	32 mm	20 x 20 mm	27 x 27 mm	32 x 32 mm	48/38 x 48/38 mm
	Plate hole \varnothing	4 mm	4 mm	4,4 mm	5,1 mm	5,1 mm	6,3 mm
	Compatible with blind hole \varnothing	8 mm	8 mm	8 mm	8 mm 10 mm	8 mm 10 mm 11 mm	10 mm 11 mm
	Additional castor height with this fitting*	+7 mm - +11 mm	+7 mm - +11 mm	+9,5 mm - +11 mm	+8 mm - +12 mm	+8 mm - +12 mm	+8,5 mm - +11 mm

* Please contact us for detailed information of the additional castor height with fitting.

EXPANDING FITTINGS FOR TUBES

Adjustable expanders allow for a flexible installation in different tube sizes. These are available for all castors with blind holes with a 10 mm diameter. The expanders and the threaded stems are pre-assembled.



Stem with plate

P41

65 x 65 mm

47/42 x 47/42 mm

6,3 mm

10 mm
11 mm

+7 mm -
+10 mm



Expanding fitting

Adjustable to different tube diameters. Available for round and square tubes.

Blind hole

Faster assembly thanks to easy plug-in fittings.



Technical data and availability



Description	Fitting type	Expander, round	Expander, square
	Article description	R07	R47
	Expander measurements	Ø 19 - 21,5 mm Ø 21,5 - 24 mm Ø 24 - 27 mm Ø 27 - 30 mm Ø 31 - 35 mm	Ø 21,5 - 24 mm Ø 24 - 27 mm Ø 27 - 30 mm Ø 32 - 35 mm Ø 36 - 40 mm
	Compatible with blind hole Ø	10 mm	10 mm

PLUG-IN STEM FITTINGS

For all castors with a blind hole fitting, different plug-in stem fittings are available to allow for a fast and efficient assembly.



Technical data and availability

					
Description 	Fitting type	Stem with grooves	Stem with circlip	Stem with circlip	Collar stem
	Article description	R10	B11	B11	B20
	Stem measurements (Ø x Length)	8 x 10 mm 8 x 20 mm 8 x 28 mm	8 x 33 mm	10 x 33 mm	7 x 36 mm
	Compatible with blind hole Ø	8 mm	8 mm	10 mm	8 mm
	Additional castor height with this fitting*	+2,5 mm - +4 mm	+0 mm	+0 mm	+3,5 mm - +5 mm

* Please contact us for detailed information of the additional castor height with fitting.

** Just collar stem B10 in 11 x 20 mm is also available for blind hole Ø 8mm.



Collar stem with circlip

Collar stem with circlip

Collar stem with circlip

Collar stem with synthetic circlip

B10

B10

B10

B40

10 x 20 mm
11 x 20 mm
11 x 30 mm

11 x 30 mm

9 x 24 mm

11 x 20 mm

8 mm**
10 mm

11 mm

10 mm

10 mm
11 mm

+2 mm -
+5,5 mm

+4 mm

+4 mm

+2 mm -
+4,5 mm

SOCKETS

Plug-in collar stem fittings can be used with different sockets for easy, stable assembly under different applications.



Technical data and availability



Description	Socket type	Round socket for tubes or wooden furniture	Round socket for tubes	Square socket for tubes	Round socket for wooden furniture	Round socket made of zinc die cast for wooden furniture
	Article description	R20	R20	R40	H40	R21
	Compatible with product	B20 7 x 36 mm	B10 11 x 30 mm	B10 11 x 30 mm	B10 11 x 30 mm	B11 8 x 33 mm
	Socket \varnothing / collar \varnothing	10 / 18 mm* 12 / 17 mm 13 / 17 mm 14 / 17 mm 16 / 20 mm 18 / 20 mm 20 / 23,5 mm 23 / 25 mm	14 / 18 mm 15 / 18 mm 16 / 18 mm 17 / 19 mm 18 / 20 mm 19 / 21 mm 20 / 21 mm 22 / 25 mm 23 / 26 mm	16 / 20 mm 17 / 19 mm 18 / 20 mm 21 / 23,5 mm 22 / 24,5 mm 23 / 25,5 mm 26 / 30 mm	15 mm	13 / 20 mm
	Socket height	27 mm	36 mm	36 mm	36 mm	26 mm

* Socket R20 in size 10 / 18 mm is without ribs and for wooden furniture, all the others for tubes. It has a height of 29 mm.

PLUG-IN THREADED STEM FITTINGS

For castors with the blind hole fitting, different plug-in threaded stem fittings are available.



Technical data and availability

Description	Fitting type	Threaded stem for profiles according to DIN 1998	Threaded stem	Threaded stem	Threaded stem	Threaded stem with groove for torx	Threaded stem	Threaded stem
	Article description	S10	S70	S70	S70	S73	S70	S70
	Threaded stem measurements in mm	7 x 25	M6 x 12 M6 x 25 M8 x 10 M8 x 12 M8 x 15 M8 x 25 M8 x 34 M10 x 10 M10 x 15 M10 x 25	M8 x 15 M10 x 10 M10 x 15 M10 x 25 M10 x 35 M10 x 50	M10 x 78	M8 x 12	M8 x 25 M10 x 15 M10 x 25	M10 x 50 M10 x 70 M12 x 25
	Compatible with blind hole Ø	8 mm	8 mm	10 mm	10 mm	10 mm	11 mm	11 mm
Overall height	Additional castor height with this fitting*	+7 mm - +8 mm	+6 mm - +7 mm	+4 mm - +7 mm	+0 mm	+0 mm	+2,5 mm	+4,5 mm

* Please contact us for detailed information of the additional castor height with fitting.

DIVERSITY WITH A SYSTEM OUR CASTORS

All of our products have their own specific qualities and strengths. Whether it's high design standards, specialist applications or exceptional load capacities – our range can meet your needs and can be adapted to fit different models.

From the correct dimensions and technical specifications to the required configuration, our product families are able to offer the ideal solution – whatever you need. Contact us for more information or visit our website: www.tente.com

E-Drive



⌀ 125 mm

Alpha




⊃ 70 - 500 kg
⌀ 80 - 200 mm

Delta



⊃ 300 - 600 kg
⌀ 125 - 200 mm

Delta twin



⊃ 600 - 750 kg
⌀ 125 - 200 mm

Zeta



⊃ 300 - 800 kg
⌀ 125 - 250 mm

Kappa




⊃ 300 - 3.000 kg
⌀ 80 - 300 mm

Kappa flex



⊃ 360 - 750 kg
⌀ 160 - 200 mm

Omikron



⊃ 900 - 11.000 kg
⌀ 100 - 500 mm

Radiata



1.200 - 1.500 kg
80 mm

Scout



150 - 350 kg
160 - 200 mm

Integral



100 - 150 kg
100 - 200 mm

Integral twin



125 - 250 kg
100 - 150 mm

Linea clinic



150 - 200 kg
125 - 150 mm

Aviana care



100 kg
75 mm

Aviana



75 mm

Agila



40 - 100 kg
50 - 150 mm

Agila twin



50 - 100 kg
50 - 75 mm

Stora



60 - 160 kg
75 - 160 mm

Mono



30 - 70 kg
50 - 100 mm

Galea



60 - 100 kg
100 - 125 mm

Levina



60 - 100 kg
75 - 150 mm

Linea



40 - 150 kg
50 - 150 mm

Anika



40 - 50 kg
55 - 75 mm

Lumina



10 - 100 kg
35 - 75 mm

Stylea



40 - 100 kg
35 - 100 mm

Smiles



40 kg
50 mm

Compacta



10 - 55 kg
14 - 50 mm

EXPERTISE THAT INSPIRES

CONTACT US

We are a globally operating company supporting you on five continents. This means on-site support with service on a level playing field – along with in-depth knowledge. Additionally, our solution experts will advise you on the best mobility concept for your needs. Visit our website to find your nearest TENTE location: www.tente.com/locations

INCREASE YOUR EFFICIENCY

Our intelligent mobility solutions help you save time, effort, energy, and operating expenses. This allows you to improve your operating methods and working conditions, thereby optimising your processes and ensuring higher productivity, profitability and safety. Ask for our solutions catalogue or read about how our customers benefit from our tailor-made solutions on our website: www.tente.com/solutions

SAVE DEVELOPMENT TIME

On our website you will also find technical drawings, product data sheets and 2D and 3D CAD files in various formats: www.tente.com/lumina


GET MORE INFORMATION

In addition to our informative website, you can easily download various catalogues and brochures on mobility solutions, customer references, and much more: www.tente.com/download



ER LIFE.

ETP



www.tente.com



PRODUCTIVITY



SAFETY



DESIGN



DURABILITY



ENVIRONMENT